

	<b>Originalbetriebsanleitung</b>	<b>WIG-Schweißplatzausrüstung</b>
<b>D</b>	Translation of the original instructions	Accessory Equipment for WIG Welders
<b>GB</b>	Translation of the original instructions	Accessory Equipment for WIG Welders
<b>F</b>	Traduction du mode d'emploi d'origine	Accessoires pour postes à souder WIG
<b>I</b>	Traduzione del Manuale d'Uso originale	Accessori per saldatrici WIG
<b>NL</b>	Vertaling van de originele gebruiksaanwijzing	WIG-lasplaatsuitrusting
<b>CZ</b>	Překlad originálního návodu k provozu	Príslušenství pro svářečky WIG
<b>SK</b>	Preklad originálneho návodu na prevádzku	Príslušenstvo pre zväračky WIG
<b>H</b>	Az eredeti használati utasítás fordítása	WIG hegesztőgép tartozékai
<b>SLO</b>	Prevod originalnih navodil za uporabo	Varilna oprema WIG
<b>HR</b>	Prijevod originalnog naputka za uporabu.	Oprema za zavarivanje WIG
<b>BG</b>	Превод на оригиналната инструкция	Акcesoари за заваряване WIG
<b>RO</b>	Traducerea modului original de utilizare	Accesorii pentru aparate de sudură WIG




## WIG-SCHWEIßPLATZAUSRÜSTUNG

41690




GÜDE GmbH & Co. KG  
Birkichstrasse 6  
74549 Wolpertshausen  
Deutschland





D **Montage**  
 GB Assembly  
 F Assemblage  
 I Montaggio  
 NL Montage  
 CZ Montáž  
 SK Montáž  
 H Szerelés

SLO Montaža  
 HR Montaža  
 BG Монтаж  
 RO Montaj  
 BIH Montaža



D **Montage**

GB Assembly

F Assemblage

I Montaggio

NL Montage

CZ Montáž

SK Montáž

H Szerelés


SLO Montaža

HR Montaža


BG Монтаж

RO Montaj


BIH Montaža




4




5




6



7



8



GÜDE GmbH & Co. KG  
Birkichstrasse 6  
74549 Wolpertshausen  
Deutschland  
Tel.: +49-(0)7904/700-0  
Fax.: +49-(0)7904/700-250  
eMail: [info@guede.com](mailto:info@guede.com)

